

Field User Guide

inReach Mini 2

Device and Mobile App Resource

Device Overview Internal Iridium® antenna Buttons USB port (under weather cap) SOS button (under protective cap) Power button 🖰



4

Sending a Quick Message

Tip: Manage up to 20 Quick Messages in the Hub at the device or team folder.

- 1. From the clock screen, press OK (Main Menu) > OK (Send Message).
- 2. Select a contact, then press OK (Next).
- 3. Use ▲ or ▼ to scroll and select a Quick Text.
- 4. Select ✓ when you have chosen your pre-written message > press OK to send the message.

Note: After saving changes in the Hub, complete a USB sync to apply message configuration updates to your device.

Mounting screw





Sending a Preset Message

- 1. From the clock screen, press OK (Main Menu) > ↓ > OK (Check In).
- 2. Select a message > OK.
- 3. Press OK (Send) to send your message.
- Preset Messages are preloaded, one-touch messages sent to assigned contacts.



Registering Your Device with the EVERYWHERE App

Tip: If you weren't provided with a Configuration Key, try entering your email. If you don't receive an email, contact your Hub User administrator or EVERYWHERE Support to have your email assigned and complete your registration.

REGISTRATION STEPS

- 1. Download & Install: Get the EVERYWHERE App from the App Store or Google Play Store.
- 2. Accept the Terms: Review and accept the End User License Agreement.
- 3. Enter Configuration Key: Input your unique key.
- 4. Message History Prompt: When asked, select "No", unless you're restoring messages. 5. Enable Permissions: Allow access to
- Location, Bluetooth, Notifications, and Contacts (optional).
- 6. Bluetooth Pairing: Tap "Yes" to pair with your device now, or "No" to set it up later.

Note: Bluetooth pairing may require extra steps on the device.

Buttons

- Press to scroll through menus, pages, and settings.
- Press to cancel or return to the previous page.
- Press to choose an option or to acknowledge a OK
 - From the home page, select to open the main menu.
- Press and hold to turn the device on. Press to open the power menu and power off.



USB Syncing the Device

Tip: A USB sync ensures that Contacts, Preset Messages, Quick Messages set in the EVERYWHERE Hub (at the device or team folder level) will appear on your device, along with other user contacts from your team. For App Users, Contacts simply update over the air.

SYNC STEPS

- 1. Download the configuration file: Get it from the Hub (if you have access), or request it from your Hub User administrator or EVERYWHERE Support.
- 2. Connect your inReach Mini 2: Use the Garmin USB-C data cable to connect to your computer.
- 3. Transfer the file: Drag and drop the configuration file into the root folder of the device.
- 4. Eject and restart: Safely eject the device, restart it, and follow on-screen prompts to apply changes.

Status Icons

- Transmitting data
- Tracking enabled
- Navigating
- * Bluetooth connection status
- Sounds muted **I**×
- Unread messages
- Charging battery 4
- * Approaching min. operating temp.
 - Approaching max. operating temp.

Testing Your Signal



Tip: Before heading out, make sure your device is functioning properly and your satellite service is active.

M DEVICE STEPS

- 1. From the clock screen, press OK (Main Menu) > ↑↑↑ > OK (Service Plan) > OK (Test Service) > OK (Yes: Begin Test).
- 2. Ensure the device has a clear view of the sky.
- 3. Wait for "Test Successful (√)" to appear.



Activating Your Transferred Device

₽₽.

Tip: If your device was purchased directly from EVERYWHERE, you can skip these steps.

- 1. PERFORM A FACTORY RESET
 - → From the clock screen, press OK (home page) $> \uparrow > OK$ (Settings) $> \uparrow > OK$ (System) $> \uparrow > OK$ (System) ↑↑↑ > OK (Reset Device) > ↓ > OK (Delete Data and Reset Settings) > ↓ ↓ > OK (Continue).
- 2. ACTIVATE THE DEVICE (Requires a clear view of the sky)
 - → Turn on the device > press **OK** (Select Language) > choose your language.
 - → When prompted with "To get started...", press: OK (Ignore it) > ↓ > OK (Skip) > OK (Activate Now) > OK (Ignore it) > OK.
 - → Wait up to 20 minutes for the screen to display "Activation Complete".

3. ENABLE AUTO TRACK

- → From the clock screen (home page), press OK (home page) > ↑ > OK (Settings) > OK (Tracking).
- → Press ↑, then ensure Auto Track is On.

Note: Ignore prompts to download the Garmin Messenger app. It must not be installed to pair your device with the EVERYWHERE App.

Pairing the EVERYWHERE App with Your Device



ON THE DEVICE

- 1. From the clock screen, press OK (home page) > \uparrow > **OK** (Settings) > $\uparrow\uparrow\uparrow$ > **OK** (Phone).
- 2. Verify Bluetooth Status shows "Waiting for Phone" > ↓ > OK (Pair Phone).

Note: Always ignore any prompts to download Garmin apps.

Activating & Cancelling an SOS



ON THE APP

- 1. Tap Settings > Bluetooth Pairing and Status > tap Pair.
- 2. Find the Pairing Code matching your device > tap the circle to select the device > OK.
- 3. Verify Bluetooth is shown as " * Connected" at the top-left of the App status bar.

sos

DECLARING AN SOS

- 1. Lift the protective cap from the SOS button.
- 2. Press and hold the SOS button to start the countdown.
- 3. Wait for the device to send an SOS message with your location to Garmin Response (emergency response service).
- 4. Confirm receipt of the message by issuing a reply (Rescue will proceed even if no reply is received).

Do not press the SOS button to test it.

Note: Once confirmed, the device returns to normal operation.



CANCELLING AN SOS

- 1. Press and hold the SOS button to begin cancellation.
- 2. Select "Yes" to confirm.
- 3. Wait for a confirmation message from Garmin Response.